


























# Automatika Slunce-Vítr GF0024, GF0025



rádiový kód zaučit

- 1**    volt
- 2**    → 
- 3**    →  3 sek.
- 4**  →    
 
- 5**  →   →  1 sek.
- 6**  →    
 
- 7** **PŘIPRAVENÝ!** 