



## Handheld transmitters GF1250/GF1251

The hand-held transmitters GF1250/GF1251 allow the simultaneous control of two different sun protection systems with the sun automatic function.

Channel 1: Extension key  Retraction key   
Channel 2: Extension key  Retraction key 

The four upper keys (right and left) allow the extension and the retraction of the sun protection system. The lower pair of keys has a special function to turn on or off the sun automatic function.

Sun automatic ON  Sun automatic OFF 

The code setting is realized through a coding switch in the handheld transmitter.

Transmit frequency: 433,92 MHz

The transmitter complies with the relevant technical regulations enacted by the European Community. It bears the CE mark and is authorized for use in all EU member states and in Switzerland without any need of prior registration.

To learn more about the EC Declaration of Conformity pertaining to this hand-held transmitter, please visit our website at: [www.geiger.de](http://www.geiger.de)

To make a code setting or to replace the battery, remove the crosshead screw at the back of the housing in order to open the battery compartment.

Use the DIP switches 1 - 7 in order to set the desired individual codings. The DIP switches 8 + 9 remain in the middle position as the channel assignment is fixed.

In the event the LED doesn't light up if actuating one of the control keys, the batteries need to be replaced.

Battery: 2 x 1,5 V, type AAA

**Spent batteries must be disposed of in compliance with the relevant national rules currently operative and in force.**

